

DIMENSIONS This end of the mounting base should always be 34 26 installed upwards. Ø26 1.0 3 ē MOUNTING INSTRUCTION Remove the mounting base from the luminaire by loosening the socket screw. 2 Mount the mounting base on the wall with screws (screws are not 2 included). 4 1 **3** POWER CONNECTION Connect to 220-240V. Connect the mounting base earth cable. 350° ٩ 90° tilt angle rotation angle 4 Fix the luminaire on the base with the socket screw. Mounting base: 133




WEVER & DUCRÉ


LIGHTING

WEVER & DUCRÉ BV Spinnerijstraat 99/21, 8500 Kortrijk, Belgium weverducre.com



INSTALLATION INSTRUCTIONS | NOVEMBER 2022







The light source is replaceable by an authorized professional. For advice contact your Wever & Ducré customer service contact point.



This luminaire contains a light source with the energy class E.



WEVER & DUCRÉ BV Spinnerijstraat 99/21, 8500 Kortrijk, Belgium weverducre.com